



FluidFlow

Quick Start Manual

Owned and Copyright by Flite Software NI Ltd

Table of Contents

Foreword	0
Part I Piping Systems FluidFlow	1
1 Welcome	1
2 Installation	1
3 Activation	1
4 Keeping your Software Current	5
5 Network Issues	6
6 Starting the Application (Network Module)	13
7 Changing User Access Information (Network Module)	13
8 Application Layout	15
9 Auto Equipment Sizing Example	16
10 Design of a Cooling Water System - Part 1	20
11 Design of a Cooling Water System - Part 2	37
12 Design of a Tank Farm Gas Collection System	43
13 Configuration and Environment	45
14 Databases	46
15 Fluids Database	46
16 Database of Manually Operated Valves	48
17 Add a New Pump	51
Index	53

1 Piping Systems FluidFlow

1.1 Welcome

Welcome to Piping Systems FluidFlow a state-of-the-art fluid flow simulator. This software application allows you to simulate the flow of fluids in complex networks, taking into account the phase state of the fluid and determining heat changes. FluidFlow is more than a pipe network analysis program, it is a fully developed steady-state process-flow simulator.

System Requirements

- 1024 MB RAM (2048 MB recommended).
- All versions of Microsoft Windows & MS Windows Server since 2000.
- 180 MB of free hard disk space.
- SVGA or higher resolution monitor (XGA recommended).
- Mouse or other pointing device.

Remember, when conducting your evaluation of FluidFlow, help is always available. Contact us with any queries at: support@fluidflowinfo.com. We would be delighted to hear from you.

1.2 Installation

FluidFlow is supplied as a single compressed installation file - FF3SETUP.EXE. This file is available via a download from our website www.fluidflowinfo.com (preferred method).

This is a common installation file for all possible modules. Simply run the file FF3SETUP.EXE and the installer will start and take you through the setup process. You can also use the setup program to install updates into your installation folder (only executable, help files, etc., are updated; databases and your project files are not overwritten).

It is possible to install remotely if you are a network administrator. The installation does not require any registry entries and for users not wishing to use an installer (for example in locked environments) there is a zipped version of the application and associated folders.

This product has been fully tested and can also be installed to run under Citrix or Terminal Services.

If you intend to run many concurrent users across remote locations outside of a LAN, (i.e., a WAN across country borders) you need to purchase a global licence.

Once installed the software reverts to demo mode until it is activated. So the first thing you need to do after installation is to **activate** the software. There is a simple activation process for both installed and unzipped installations.

In order to install and activate you **MUST** have Windows Administrator privileges (i.e., **read/write** access) to where FluidFlow is installed. You cannot activate over a LAN or WAN without using remote access software (for example, terminal services, remote desktop, citrix, or similar), as for activation the application **MUST** be running in the server process workspace. For more information about the activation process see the [activation](#) chapter or download our [Network Installation Instructions](#) PDF.


1.3 Activation

When you first start FluidFlow it will be automatically activated for you for a two week **trial** period. Please use the email address you entered when downloading the trial to login when prompted. After the two weeks are over, you will need to activate FluidFlow. Here are the various ways to activate the software (post trial period):

License Manager Activation

Once you have installed FluidFlow, the software must be activated to unlock the full functionality. Activation is the process of configuring access to the available FluidFlow modules.

When you purchase the software or obtain a lease license you will be provided with a Username and Password. Use the information provided in the Licence Manager as shown.



FluidFlow License Manager (8th May, 2025 - 3.54)

File Options Help

Activate Deactivate Export Import

Method: Online

Username: An Engineer

Password: *****

Registered To: Fiachra

Module	Count
Liquid Calculation	0
Gas Calculation	0
Non-Newtonian & Slurry Calculation	0
Two-Phase Gas-Liquid Calculation	0

Product Id: 29A4-5B64


Expiry Date: 01/01/9999

Kind: Standalone

LIC Folder: C:\Users\Public\Documents\Flite\FluidFlow3

Activate

Click the 'Activate' button (on the bottom right) and the software will automatically obtain an activation code and activate the software. If a successful activation occurs the following message appears



FluidFlow3Im

FluidFlow Activated.

An email will be sent to your registered address to confirm this.

OK

Method: Online

Username: An Engineer

Password: *****

Registered To: Fiachra

Module	Count
Liquid Calculation	1
Gas Calculation	1
Non-Newtonian & Slurry Calculation	1
Two-Phase Gas-Liquid Calculation	1

Product Id: 29A4-5B64

Expiry Date: 01/01/9999

Kind: Standalone

LIC Folder: C:\Users\Public\Documents\Flite\FluidFlow3

Activate

Alternative Activation Methods

All of the alternative activation methods that were available prior to v3.30 are still available and these are described below.

You can use the 'Help | Activate FluidFlow...' menu option, which will display the dialog below.

Click on the "How to Register" tab and select one of the available registration methods.

Activate FluidFlow 3.54

Activate Transfer License How To Register

There are three ways to register FluidFlow and receive an Activation Code:

1. When you receive a Username and Password go to <https://www.fluidflowinfo.com> (or click "Register via Internet" below), click on "Login", select "Generate Activation Code" from "Your Details", enter your Product Id (29A4-5B64), and copy the result into the area provided on the Activate page. Register via Internet
2. Ring Flite on Intl+44 2871 279227. You will need to quote your Product Id (29A4-5B64), specify a Registration Name, and the Modules you require.
3. E-mail sales@fluidflowinfo.com. You will need to include your Product Id (29A4-5B64), a Registration Name, and the Modules you require. Register via E-mail

Note: If you use a web-based e-mail client, or experience trouble with the 'Register via E-mail' button, please copy the following text - be sure to specify the required Modules and Registration Name - and e-mail it to sales@fluidflowinfo.com:

I would like to register FluidFlow3 and receive an Activation Code.

Product ID = 29A4-5B64
 Registration Name = [Enter Registration Name Here]
 Required Modules = [Enter Required Modules Here]

Available Modules = Liquid Calculation, Gas Calculation, Non-Newtonian & Slurry Calculation, and Two-Phase Calculation.

Copy to Clipboard

Close Help

The software generates a Product Id (29A4-5B64 in the example above) directly from your computer. Simply email this Product Id together with the calculation modules you need, or have purchased, to support@fluidflowinfo.com and an activation code and registration name will be provided (usually by return).

On receipt of your activation code and registration name (you can specify the registration name if you wish in the email you send to us), click on the "Activate" tab and enter the information you have received as shown below.

Assuming we have received the following activation data:

Registration Name: Flite Software NI Ltd

Activation Code:

0A0306A5365AAF07A3F28D3FA20BFB5C7BE5682AB8571C880EBF57FD384AB966A91D7A987EE0338F7ED
 FBF57FD384AB966A922ADEA59EF25E4187DBF57FD384AB966A9A3BFF345B0BA0CEACBAF6A2F91110948
 29563E472CE22F9180EFAF6A2F911109482940AF7E349247A69F8BF57FD384AB966A932CCEDCABF38D8F
 F4AF6A2F9111094829DBAEB3D1623F8B8BAF6A2F9111094829256BDC8D142CD1ED6AF6A2F911109482
 918FF732900F4D7F42AF6A2F91110948291

Copy and paste this information from your email.

Activate FluidFlow 3.54

Activate Transfer License How To Register

Please enter your Registration Name and Activation Code. If you have not yet registered FluidFlow then use one of the options on the 'How To Register' page to register and receive your Activation Code.

Note: To add new module licenses contact Flite to receive a new Activation Code.

Product Id: 29A4-5B64 (on Client) / 29A4-5B64 (on Server)

Modules:

Module	Licenses
Liquid Calculation	2
Gas Calculation	2
Non-Newtonian && Slurry Calculation	2
Two-Phase Gas-Liquid Calculation	2

Kind: Network Version

LIC Folder: C:\Users\Public\Documents\Flite\FluidFlow3

Registration Name: Flite Software NI Ltd

Activation Code: 0A0306A5365AAF07A3F28D3FA20BFB5C7BE5682AB8571C880EBF57FD384AB966A91D7A987EE0338F7EDFBF57FD384AB966A922ADEA59EF25E4187DBF57FD384AB966A9A3BFF345B0BA0CEACBAF6A2F9111094829563E472CE22F9180EFAF6A2F911109482940AF7E349247A69F8BF57FD384AB966A932CCEDCABF38D8FF4AF6A2F9111094829DBAEB3D1623F8B8BFAF6A2F9111094829256BDC8D142CD1ED6AF6A2F911109482918FF732900F4D7F42AF6A2F91110948291

Activate FluidFlow

Close Help

Click the 'Activate FluidFlow' button and the Registration Id will now contain a code instead of Evaluation Version and the modules that you have purchased will become available.

If you are activating a network version then you should also read the [network issues](#) section for additional information.

Email Activation

If you choose to activate the software by email, please follow the steps outlined below.

Start FluidFlow and select the 'Help | Activate FluidFlow...' menu item:

Activate FluidFlow 3.54

Activate Transfer License How To Register

Please enter your Registration Name and Activation Code. If you have not yet registered FluidFlow then use one of the options on the 'How To Register' page to register and receive your Activation Code.

Note: To add new module licenses contact Flite to receive a new Activation Code.

Product Id: 29A4-5B64

Modules:

Module	Licenses
Liquid Calculation	1
Gas Calculation	1
Non-Newtonian && Slurry Calculation	1
Two-Phase Gas-Liquid Calculation	1

Kind: Standalone Version

LIC Folder: C:\Users\Public\Documents\Flite\FluidFlow3

Registration Name:

Activation Code:

Activate FluidFlow

Close Help

Email the Product ID to support@fluidflowinfo.com. In this case, the Product ID is 29A4-5B64. The FluidFlow team will then reply with a **Registration Name** and **Activation Code** which you can use to activate the software.

Copy and paste the **Registration Name** and **Activation Code** into the relevant sections of the "Activate FluidFlow" dialog, taking care to ensure there are no spaces between characters of the activation code. Now you can select the "Activate FluidFlow" button and then close the dialog.

Note, you will need to exit and restart FluidFlow to complete the activation process.

1.4 Keeping your Software Current

Flite Software has a commitment to constant improvement of the FluidFlow product. In addition we provide an undertaking to attempt to fix bugs (and annoyances) in a timely manner. This commitment means that the FluidFlow product is constantly improving and so it is in your interest to stay current by using the latest release.

It is your responsibility to keep your software current via our [website](http://www.flite.co.uk). You can check whether a new update is available via the 'Help | Check For Updates' menu item.

1.5 Network Issues

Note: This section is only relevant if you have the Network module.

Installation Instructions

- Download FF3SETUP.EXE, and either physically at your server, or connecting via Remote Desktop Connection (or similar software), run the installation application.
- When installing FluidFlow3 on your network server, select "Network Server" from the Installation Kind, when prompted. This will create a PSFF.INI (text) file, with a NetworkAccessFolder entry that points to the location of the license file on your server.

See NOTE 1 (below) for information about configuring your FluidFlow3 network installation.

- Activate FluidFlow3 on your network server to create the license file in the folder pointed to by PSFF.INI | NetworkAccessFolder.

Note: You will need to do this either physically directly at the server machine, or via Terminal Services/RDC.

To "activate":

- Start the FluidFlow3 License Manager (FluidFlow3LM.EXE) located in the same folder as PSFF.EXE on your server.
- Go to the 'Activate' page.
- Enter:

Username: *****
Password: *****
- Click the 'Activate' button.

See NOTE 2 (below) for information about activating your FluidFlow3 network installation.

- Start FluidFlow3 on your server – username: Administrator; password: psff
- Select the 'Database | Configure Users...' menu item and add your FluidFlow3 users.
- Provide your users with a link to PSFF.EXE on your server.

See NOTE 3 (below) for information about sharing your FluidFlow3 application folder and creating a shortcut link.

NOTE 1: Configuring your Network Installation (Sharing Folders and Setting Permissions)

When you install FluidFlow3 the setup program creates a configuration text file - PSFF.INI - in the same folder as the application (PSFF.EXE), typically in "C:\Program Files (x86)\Flite\FluidFlow3".

This file will contain three entries: the location of the equipment data (DataFolder); the location of the user preferences (PreferencesFolder), and the location of the license file (NetworkAccessFolder). These are the only folders in FluidFlow3 that users **need** to have **read-write** access to for the application to function correctly. The FluidFlow3 application folder requires only **read** access.

FYI: The DataFolder needs to be read-write so that you can edit Line Equipment items such as Valves and Boosters via the 'Databases' menu items. The PreferencesFolder is where FluidFlow3 stores user-specific settings, e.g., 'Options | Calculation'. The NetworkAccessFolder is where the application tracks who is logged on against what is valid for the license.

The PSFF.INI entries default to folders under "[Public Documents]\Flite". The "Public Documents" folder is typically "C:\Users\Public\Documents". You can determine where it is on your machine by putting %PUBLIC% into the address bar of Windows Explorer.


When you do a network installation – by selecting "Network Server" from the Installation Kind options (when you run FF3SETUP.EXE) – your PSFF.INI will look like:

```
[Options]
DataFolder=\\YourServer\C$\Users\Public\Documents\Flite\FluidFlow3\Data
PreferencesFolder=\\
YourServer\C$\Users\Public\Documents\Flite\FluidFlow3\Preferences
NetworkAccessFolder=\\YourServer\C$\Users\Public\Documents\Flite\FluidFlow3
```


Note: *YourServer* will be replaced by the name of your server machine.

IMPORTANT: This is where an issue might arise as FluidFlow3 assumes the C drive will be shared when you perform a network installation. We would recommend that you do **not** share the C drive itself, but share the "[Public Documents]\Flite\FluidFlow3" folder instead.

To do this: right-mouse click the "[Public Documents]\Flite\FluidFlow3" folder name in Windows Explorer. Select 'Properties | Sharing | Advanced Sharing' and check the 'Share this folder' option:



Click the 'Permissions' button and give full control to the 'Everyone' group:



If you share the FluidFlow3 folder (as described above), you need to modify PSFF.INI to reflect that. For example:

[Options]

DataFolder=\\YourServer\\FluidFlow3\\Data

PreferencesFolder=\\YourServer\\FluidFlow3\\Preferences

NetworkAccessFolder=\\YourServer\\FluidFlow3

NOTE 2: Activating FluidFlow3

There are a few ways to activate FluidFlow3, however, for a Network license activation, you **do** need to have access to the server machine (either physically, or via Terminal Server/Remote Desktop Connection/similar software.) This access is required to be able to get the correct Product Id (i.e., the Hard Disk Serial No.) for the server, or to run the FluidFlow3 License Manager.

Activating FluidFlow3 (via the FluidFlow3 License Manager - FluidFlow3LM.EXE):

NOTE: Depending on the version of your existing installation, you may not have this application. It can be downloaded from <https://portal.fluidflowinfo.com/ffdownloads/v3/FluidFlow3LM.zip>. Unzip this to the same folder as the FluidFlow3 application (PSFF.EXE) on your server.

- Ensure that FluidFlow3 is not running on the server machine.
- Start the FluidFlow3 License Manager (FluidFlow3LM.EXE) on the server machine (either physically or remotely logging in.)
- Select the 'Activate' page, and enter your Username and Password. Please contact sales@fluidflowinfo.com (or your local distributor) for your Username and Password, if you do not have them.
- Click the 'Activate' button.

Activating FluidFlow3 (via Activation Code):

- Start FluidFlow3 on the server machine (either physically or remotely logging in.)
- Select the 'Help | Activate FluidFlow...' menu item and make a note of the Product Id.
- Send this Product Id to sales@fluidflowinfo.com (or your local distributor) and an Activation Code will be generated and emailed back to you.
- In the 'Activate FluidFlow' dialog, paste the code into the 'Activation Code' input area, along with the 'Registration Name' provided.
- Restart FluidFlow3.

NOTE: You can generate the Activation Code yourself by logging into your account on our server:

- Start FluidFlow3 on the server machine and get the Product Id from the 'Help | Activate FluidFlow...' menu item.
- Log in to your account on our server (<https://portal.fluidflowinfo.com/portal/login.php>). Please contact sales@fluidflowinfo.com (or your local distributor) for your Username and Password, if you do not have them.
- Select 'Generate Code' from the 'Your Info' drop-down.
- Ensure the correct Product Id is entered.
- Click the 'Generate Activation Code' button.

- Copy and paste the generated code into the 'Activate FluidFlow' dialog in FluidFlow3 and restart the application.

Activating FluidFlow3 (via License File - FF3.LIC):

- Start FluidFlow3 on the server machine (either physically or remotely logging in.)
- Select the 'Help | Activate FluidFlow...' menu item and make a note of the Product Id.
- Send this Product Id to sales@fluidflowinfo.com and a License File (FF3.LIC) will be created and emailed back to you.
- Stop FluidFlow3.
- Copy the FF3.LIC License file to the NetworkAccessFolder on the server.
- Restart FluidFlow3.


NOTE: The location of the "NetworkAccessFolder" is specified in the PSFF.INI file.

NOTE 3: Client Setup


After installing and activating FluidFlow3 on the network server you can setup the client machine by placing a link on the client's desktop to the FluidFlow3 application (PSFF.EXE).

For a client to be able to access the FluidFlow3 application, the folder it is located in on the server must be shared for read access. Typically FluidFlow3 is installed into the "C:\Program Files (x86)\Flite\FluidFlow3" folder on your server.

To share this folder as FluidFlow3App, for example: right-mouse click the "C:\Program Files (x86)\Flite\FluidFlow3" folder name in Windows Explorer. Select 'Properties | Sharing | Advanced Sharing' and check the 'Share this folder' option:



Click the 'Permissions' button and allow 'Read' for the 'Everyone' group:



You can now create a shortcut link that clients can use:

- Right-click on the desktop and select the 'New | Shortcut' menu item.
- Enter the location of the PSFF.EXE file, e.g., '\\YourServer\FluidFlow3App\PSFF.exe' and click 'Next'.
- Enter the title for the shortcut, e.g., 'FluidFlow3 (Network)' and click 'Finish'.

Help Files on the Network

Security updates to Microsoft Windows have introduced some severe restrictions for accessing HTML Help (CHM) files across network drives. Under Windows most file links in HTML Help files will now generally not work at all and HTML Help itself is also severely restricted. Without registry changes on the user's computer, HTML Help now cannot be used at all on networks. This has an effect on the FluidFlow3 Network Version as all client machines that try to display the Help file will receive a "Page not found" message.

More details and a fix for this problem are available on the Help & Manual (http://www.helpandmanual.com/products_hhreg.html) website.

Alternatively, there is a workaround to allow a client machine to display Network-based HTML Help files, but it does involve modifying the Registry on the client machine. To do this:

1. Click 'Start', click 'Run', type 'regedit', and then click 'OK'.
2. Locate and then click the following subkey:

HKEY_LOCAL_MACHINE\SOFTWARE\Microsoft\HTMLHelp\1.x\ItssRestrictions

Note: If this registry subkey does not exist, create it. To do this, follow these steps:

- a. On the 'Edit' menu, point to 'New', and then click 'Key'.

- b. Type 'ItssRestrictions', and then press 'ENTER'.
4. Right-click the ItssRestrictions subkey, point to 'New', and then click 'DWORD Value'.
5. Type 'MaxAllowedZone', and then press 'ENTER'.
6. Right-click the MaxAllowedZone value, and then click 'Modify'.
7. In the Value data box, type '1', and then click 'OK'.

This will allow you to access CHM files on a shared network folder. For more information see:
<http://support.microsoft.com/?kbid=896054>

Note: Always make a backup of the Registry before making any modifications so that you can 'rollback' the changes if anything goes awry. To do this, run Regedit, select the 'File | Export' menu item, select the 'All' option from 'Export Range', enter a filename and click 'Save'. You can later use the 'File | Import' menu item if you want to revert to your original Registry.

Help Files on the Network - Alternative Solution

FluidFlow3 also supports browser-based help. If you wish to use this please download the FF3BHELP.ZIP file from our website - <https://portal.fluidflowinfo.com/ffdownloads/v3/FF3BHelp.zip> - and unzip it to the FluidFlow3\Help folder to give \FluidFlow3\Help\FFEnglish and \FluidFlow3\Help\QuickStart folders.

For FluidFlow3 to use this, create PSFF.INI (if it does not already exist) in the same folder as PSFF.EXE and add an Options | UseBrowserHTMLHelp entry:

[Options]

UseBrowserHTMLHelp=1

Troubleshooting

The most usual issues reported for network installations and their resolutions are given below:

1. Unable to Activate

This is because you are trying to activate from a client machine. This is not possible because you are running the application in the client workspace and not the server workspace. For the purpose of activation **ONLY**, you can overcome this issue by connecting to the server via remote desktop (terminal services, citrix etc) or being physically present at the server to activate. So to activate a network version, run the application via remote desktop, or be physically at the server.

Another possible reason for "unable to activate" is because you do not have the correct read/write/modify permissions to the folder (and all sub folders) where FluidFlow is installed.

2. "User Limit [1] reached. No more users allowed." message always displayed no matter how many licenses. This is caused by the incorrect sharing of the FluidFlow folder. For more information see the Network Installation section above.


1.6 Starting the Application (Network Module)

If you have the network module activated the product starts slightly differently to the start-up of the stand-alone version. If you do not have the network module activated then skip this section.

The first step in the start-up for a network user is a simple Logon screen:

- Select your username from the list and enter the password given to you by the system administrator.
- Select from the available licenses the calculation functionality you will need.
- Press the OK button and the application will start up.

In the below example the user 'Administrator' will be using 3 modules from a total pool. (Note, the default 'Administrator' password is: PSFF)



FluidFlow Network Logon v3.53

Username: Administrator

Password:

Select the modules you require:


Module	Available	Total
<input checked="" type="checkbox"/> Liquid Calculation	2	2
<input checked="" type="checkbox"/> Gas Calculation	2	2
<input type="checkbox"/> Non-Newtonian & Slurry Calculation	2	2
<input checked="" type="checkbox"/> Two-Phase Gas-Liquid Calculation	2	2

3.53/29A45B64/29A45B64

Start in non-Calc Mode ☐

OK Cancel

The next user to log on will see the following Logon dialog.



FluidFlow Network Logon v3.53

Username: fiach

Password:

Select the modules you require:

Module	Available	Total
<input type="checkbox"/> Liquid Calculation	1	2
<input checked="" type="checkbox"/> Gas Calculation	1	2
<input type="checkbox"/> Non-Newtonian & Slurry Calculation	2	2
<input type="checkbox"/> Two-Phase Gas-Liquid Calculation	1	2

3.53/29A45B64/29A45B64


Start in non-Calc Mode ☐

OK Cancel

Notice that there are now less modules available as Liquid, Gas, and Two-Phase modules were taken by the 'Administrator' who logged on first.

1.7 Changing User Access Information (Network Module)

To be able to make changes to user information you must log on to the application as 'Administrator'. The default 'Administrator' password is PSFF. Log on as 'Administrator' as shown below:



FluidFlow Network Logon v3.53

Username: Administrator

Password:

Select the modules you require:

Module	Available	Total
<input checked="" type="checkbox"/> Liquid Calculation	2	2
<input checked="" type="checkbox"/> Gas Calculation	2	2
<input type="checkbox"/> Non-Newtonian & Slurry Calculation	2	2
<input checked="" type="checkbox"/> Two-Phase Gas-Liquid Calculation	2	2


3.53/29A45B64/29A45B64

Start in non-Calc Mode ☐

OK Cancel

You must select at least one module in order to start.

As 'Administrator', the application will start in the normal manner but an additional item - 'Configure Users...' - will appear at the end of the 'Database' menu. Select this menu option to show the Network Users dialog:



Network Users

User Name	Password	Connected
Administrator	psff	Yes
fiach		No

Add Edit Delete Password

OK Cancel Help

From this dialog you can add, edit, or delete users, change passwords, or just view the current connections.


Note: It is not possible to delete the 'Administrator' account.

1.8 Application Layout

The application work screen consists of two main windows. The flowsheet window where a schematic layout of the piping network is developed or built, and the data palette where data input is made, results and warnings are shown, etc.

You can have as many flowsheets open as desired. From a flowsheet viewpoint the application behaves similar to Microsoft Word's Multiple Document Interface, that is, you can tile, cascade, and select a flowsheet from the window menu or by clicking on the caption bar of the window. If you double-click the caption bar the flowsheet fills the available work area.

The data palette size can be adjusted by dragging the left side of the window border. The data palette is synchronized to the flowsheet, so if you click on a flowsheet element, the data palette is refreshed to reflect the current selections(s). This process also works in reverse, for example, if you click an element warning in the data palette, or a list item, the flowsheet selection updates to reflect this.



At the top of the work screen are three rows of operators: (1) a set of drop down menus; (2) a toolbar; (3) the component palette. The component palette consists of a series of tab options. Within each tab are the equipment item icons or elements that are used to build a fluid network.

A flowsheet toolbar is positioned along the left hand side of the screen. Options here determine how you access and utilize the flowsheet window.

1.9 Auto Equipment Sizing Example

FluidFlow includes a powerful auto-size feature which allows engineers to automatically size a range of elements such as pipes, centrifugal pumps, fans, compressors, PD pumps, orifice plates, nozzles, pressure and flow control valves. Pressure relief valves and bursting disks can also be auto-sized to API & ISO standards for liquids, gases, steam and two-phase flow systems.

This example involves designing a cooling water distribution system to a bank of heat exchangers where we shall use orifice plates to balance the flow distribution. We shall also use the auto sizing functions to develop the system design and size the pipes, pump and orifice plates.

Problem Statement:

It is desired to provide a balanced cooling water flow to four shell and tube heat exchangers HE1, HE2, HE3 and HE4. The size of the heat exchangers has already been determined from the process requirement and is summarized in table 1.

Table 1

Name	Heat Load (kW)	Tube Length (M)	Tube Diameter (mm)	Number of Tubes
HE1	370	4	20	20
HE2	250	4	20	20
HE3	370	4	20	20
HE4	250	4	20	20


The cooling water is to flow through the heat exchangers and the design system inlet temperature will be 15°C. The design temperature rise of the cooling water across each heat exchanger is 30°C. The elevation of the all elements in this model is zero. The design duty pressure rise for this system is also known, 2.5 bar.

Building the model in the FluidFlow flowsheet:

1. Place two known pressure boundary nodes on the flow sheet.
2. Using the steel pipe element, connect the known pressure boundary nodes together as per Figure 1 below.
3. Add the branch pipe connections, ensuring the branch at each tee junction is assigned correctly.
4. Insert the heat exchangers into each branch line.
5. Insert thin orifice plates into the branch pipe connection serving each heat exchanger.

The basic model connectivity should appear as set out in Figure 1.

Figure 1



If you wish that check that your data entry is correct, you can load up the example "Examples\Auto Sizing Example Rev 1" which can be found in the Examples folder.

Each element placed on the flowsheet is provided with default data which the engineer can easily edit based on known design parameters. In this case, we will define the pipe lengths as set out in Table 2. Note, we will accept the default data provided by FluidFlow for the boundary nodes.

Table 2

Pipe Number	Pipe Length (M)
-19	5
-14	5
-12	5
-20	5
-15	5
-9	5
-21	5
-16	5
-6	5
-22	5
-17	5
-2	5
-4	5
-5	5
-7	2.5
-8	2.5
-10	1.25
-11	1.25
-3	1.25
-18	1.25
-1	1

Select all the heat exchangers at once by holding the SHIFT key and left mouse-clicking on each. All heat exchangers should now be highlighted on the flowsheet. From the Input tab of the Data Palette, set the Heat Loss Model to *Fixed Transfer Rate*, the heat transfer direction to *Into the Network* and the Heat Transfer Unit to *kW*. We have now set all common parameters for the heat exchangers in one step.

The next step is to define the heat load for each heat exchanger (see Table 1).

The design pump pressure rise is 2.5 bar. We can therefore set the centrifugal pump to *Automatically Size* from the Input Tab on the Data Palette. In doing so, we have two sizing options available: *Size for Flow* and *Size For Pressure Rise*. Select *Size For Pressure Rise* and defined the Design Pressure Change as 2.5 bar.

Using the data available for the heat exchangers, we can determine the design mass flow rate from the heat balance ($Q = m \times c \times \Delta T$). The heat transferred to the cooling water will therefore be:

$$\text{Heat Transferred (W)} = \text{mass flow (kg/s)} \times \text{specific heat capacity (J/kg)} \times \text{temperature rise (}^{\circ}\text{C)}$$

The specific heat of water at 30°C is approx 4154 J/kg, so from Table 1 we see that the mass flow needed to HE1 will be $370000 / (4154 \times 30) = 2.969$ kg/s. Summarizing in Table 3.

Table 3

Heat Exchanger	Mass Flow (kg/s)
HE1	2.969
HE2	2.006
HE3	2.969
HE4	2.006
Total	9.95 kg/s


Since we can auto-size our components, we can define the design flow rate at each orifice plate by setting the *Automatically Size* option on the Input tab of the Data Palette to *On*. We now have two sizing models to choose from, *Size for Flow* and *Size for Pressure Loss*. As we know the flow rate, select *Size for Flow*. The next step is to enter the mass flow rates noted in Table 3 for each orifice plate.

The Sizing Model for pipes is Economic Velocity by default. This means that FluidFlow will determine the Exact Economic Size pipe diameter based on the calculated Economic Velocity. This velocity is a function of the fluid physical properties, the pipe materials, various capital and installation costs and the operating hours/year. This value is calculated from the Generaux equation and the calculation uses the values and constants stored in the pipe sizing database. Economic velocity is changing (generally decreasing) with time, particularly as energy costs have increased rapidly in recent times. Flite Software keeps these values up to date, which is one of the many reasons you should keep your software current. Economic velocity is meant to be a guide for pipe sizing it is NOT a strict criteria for sizing pipes. For example you would not use this value to size pipes where two phase flow is present, or where plant operation is intermittent, or where materials can degrade at high velocities, or for Non-Newtonian flows.

We wish to develop an efficient system design and as such, we are going to retain the Economic Velocity sizing model.

We are now in a position to calculate the model. The solved system should appear as set out in Figure 2.

Figure 2



The flow distribution has been shown and if we view the results for any of the four heat exchangers, we can see that the inlet temperature is 15°C and the outlet temperature is 45°C (based on our design 30°C temperature rise).

Note, we also have three warning messages indicating high velocities in the pipelines highlighted in RED.

If you wish that check that your data entry is correct, you can load up the example "\Examples\Auto Sizing Example Rev 2" which can be found in the Examples folder.

A quick check on the results for each of the pipes with a high velocity warning indicates velocities in the range of 4.5 m/s which is considered high. We therefore need to review the pipe diameter. The diameter of each of these pipes is the default value of 2 inch which is 52.5mm. FluidFlow has determined an economic pipe size of approx. 101mm for each of these three pipes. We therefore need to select the next closest standard size match. Lets try a 4 inch schedule 40 pipe.

You can multi-select the three pipes by holding the SHIFT key and left mouse-clicking on each pipe. From the Input tab on the Data Palette, access the pipes database and change the pipe to 4 inch schedule 40 pipe. Press Calculate to refresh the results for the system.


If we view the results for the orifice plates, we can see that FluidFlow has automatically determined the K value and the size of orifice required to provide the desired mass flow rate. The pump duty has also been established for us as 9.95 kg/s @ 2.5 bar (26 m fluid).

The warnings have also been corrected and as such, it can be considered that the system is now a relatively efficient design.

Based on the data entry, FluidFlow has therefore automatically sized the pipework, pump and orifice plates for us, thus simplifying the design process and reducing design time considerably.

If you wish that check that your data entry is correct, you can load up the example "\Examples\Auto Sizing Example Rev 3" which can be found in the Examples folder. The final design should appear as set out in Figure 3.

Figure 3



Design Note:

When using the auto size function, it's important not to over constrain the model as this could lead to model convergence difficulties. For instance, in this example, we could have set the sizing model for the pump to *Size for Flow*. As we had effectively already defined the total flow in the system by defining the flow rate at each orifice plate, we would have duplicated the flow in the system. It is best to avoid duplicating design parameters when developing your model.

Video:

You can view a video of this example on our [YouTube channel](#).

1.10 Design of a Cooling Water System - Part 1

This example will work through the design development of a cooling water distribution system. In doing so, this exercise will demonstrate some of the unique features of the software including the powerful *auto-sizing* functionality.

The topics covered in this example design are:

- Flowsheet and model building basics.
- How to enter data.
- How to interpret results.
- How to automatically size pipes and components.

Note, FluidFlow allows engineers to auto-size pipes, pumps, orifice plates, control valves and a range of other fittings which simplifies the design process and reduces project design-time considerably.

Outline Project Brief:

It is desired to provide a balanced distribution of cooling water from a cooling tower to serve a total of three shell and tube heat exchangers HE1, HE2 and HE3. The size of the heat exchangers has already been determined from the process requirement and is summarized in Table 1.

Table 1

Heat Exchanger	Heat Load (watts)	Tube Length (M)	Tube Diameter (mm)	Number of Tubes
HE1	200000	3	0.012	130
HE2	170000	3	0.012	165
HE3	170000	3	0.012	110

Design Criteria:

- The cooling water is to flow through the tubes of each exchanger and the maximum inlet summer temperature of the cooling water will be 25°C.
- The design temperature rise of the cooling water across each heat exchanger is 10°C.
- The elevation of the exchangers above the pump centerline is 3 m and the exchangers are approximately 8 M apart.
- Each exchanger has 2 tube passes.
- The elevation of the cooling tower inlet above the pump centerline is 6m and the manufacturer of the cooling tower requires a minimum pressure loss of 30000 Pascals for the flow distribution to work effectively.

As part of the design development, we need to design/specify the following items:

- Pipe sizes to be used.
- The method we will use to balance the flow through each exchanger.
- How to make a pump selection.
- We need to consider what happens to the exit cooling water temperature of HE2 if the heat load is increased by 33%.

Building the model in the FluidFlow flowsheet:

With the design of all systems the initial question we need to answer is where do we start and end the model, i.e. where do we and how do we define the model boundaries. For this design we will start the model at the cooling tower sump and end the model at the top of the cooling tower. This means the actual cooling tower will not be included in this model. Most cooling water systems have a supply header taking fresh cooling water to each individual exchanger and a collection return header. We will therefore use this same approach.

Finally, before we start building the model we need to consider the cooling water flow rate we need to each exchanger branch. The flow to each exchanger is determined by a heat balance equation:

Heat Transferred (W) = Mass flow (kg/s) x Specific Heat Capacity (J/kg) x Temperature Rise (°C).

or simply


$$Q = m \times c \times \Delta T.$$

The specific heat of water at 30° C is approximately 4154 J/kg, so from Table 1 we see that the mass flow needed to HE1 will be $200000 / (4154 \times 10) = 4.81$ kg/s. The required mass flow rate of water to each exchanger is summarized in Table 2 below.


Table 2

Heat Exchanger	Mass Flow (kg/s)
HE1	4.81
HE2	4.09
HE3	4.09
Total	12.99 kg/s

We will now start building the model by placing three shell and tube exchangers onto the flowsheet. Select the shell and tube exchanger icon by clicking on the *Heat Exchangers* Tab on the *Component Palette*.



Place three shell and tube heat exchangers onto a new flowsheet as shown below:



As we drop each element (or component) onto the flowsheet, default data is associated with the element. The default data for each element can be seen in the *Data Palette* by clicking on the *Input Tab*. Often we need to change some value(s) in the default data to meet our needs. For now we will continue building and come back later to change each individual element as necessary.

The reason we are deferring this task is that there are many group features built into FluidFlow to aid data editing and setup, which we can use feature later.

Next we will add the two boundaries.

Inlet Boundary:

For the cooling water inlet boundary we need a boundary that can represent the cooling water sump. We know that the sump is open to atmosphere and that during normal operation the liquid level in the sump is 0.5m above the pump centerline.

If we specify the pressure at any boundary then FluidFlow will calculate the flow that will be delivered to the system. In our design we know the design flow that is needed, because this is determined by the heat load of the exchangers. Later we will make a pump selection that will provide us with the correct flow and design duty pressure rise across the system.


Select the *Known Pressure* boundary icon by clicking on the *Boundaries* Tab on the *Component Palette*. Place the *Known Pressure* element on the flowsheet anywhere below the three heat exchangers.



Outlet Boundary:

The collection return line eventually leads back to a cooling tower. At this boundary we know the pressure that we must have above in order for the system to work as the cooling tower manufacturer requires a minimum pressure loss of 30000 Pascals. The water pressure necessary at the exit boundary is the sum of the elevation we need to rise to the top of the cooling tower + any pressure required to overcome the loss in the flow distribution system feeding the cooling water tower. The elevation of the cooling tower inlet above the pump centerline is 6m. We will therefore select a *Known Pressure* element for the exit boundary.


At this point the flowsheet should look something like:




To add a pump to the system, we need to select the *Centrifugal Pump* element found on the *Boosters* tab and set the *Automatically Size* function to *On*. Note, if we set the *Automatically Size* function to *Off* and select a pump model from the database, this will represent a specific pump and the flow we obtain in the system will be that dictated by the intersection of the pump and system curves. Chances are that the default pump selection will be incorrect. We will therefore defer the selection of the actual pump model until we have sized the pipes and fittings.

As we have set the *Automatically Size* function to *On* for the centrifugal pump, this allows us to choose from two sizing options: 1) *Size for Flow* or 2) *Size for Pressure Rise*. If we select *Size for Flow*, FluidFlow will calculate the head required to deliver our design flow rate and if we select *Size for Pressure Rise*, FluidFlow will calculate the flow rate throughout the system as a result of the design pressure rise requirement.

We therefore need to consider which option is most applicable for our design case. As a first pass design, we can select *Size for Flow* and define the design flow rate of 12.99 kg/s for the system. This will enable us to size the pipework, study the flow distribution and determine the pump duty pressure rise.



Place the centrifugal pump on the flowsheet to the right of node 4 (the node *Known Pressure* node which represents the cooling tower sump).




We are now ready to start connecting pipes. FluidFlow makes pipe connecting very easy, because there is no need to include bends. These are added for you as you draw the pipes. We will again defer the task of editing data values as we connect pipes. Right now we are only concerned with building the model connectivity.

Click the Steel Pipe icon on the *Pipes* tab of the *Component Palette*.



As you move the cursor over the flowsheet the shape changes to a pipe icon. Click on the known pressure boundary and then move the mouse to be directly over the pump element, then click the left mouse button.

FluidFlow will then complete the pipe connection from the cooling water sump to the pump. While the cursor is over the pump make a second left mouse click and then move the mouse cursor to the right beneath heat exchanger 3 and make another left mouse click. A pipe is created starting at the pump and terminating at an open end. Click on the open end and the position the cursor directly over the heat exchanger as shown below.




Click on the exchanger, to complete the connection from the open end to the far right heat exchanger. Notice that the open pipe will change to a bend automatically.

If you make a mistake, click on the selector icon, in the flowsheet toolbar, select the wrongly connected element and use the *Ctrl + Delete* keys together to delete the selected element. Alternatively, right mouse-click and select "Delete" from the drop-down menu.



Selector Icon.


Your flowsheet should now appear as shown below.




Move the cursor over the pipe on the discharge side of the pump on the same grid position as heat exchanger 2. Notice how the cursor changes from a pipe to a split pipe as we move over a pipe that can be split. If we click here the pipe will be split and we can make the connection to the middle heat exchanger.

The split pipe has converted itself into a Tee connection. This type of junction, because it is made dynamically, adjusts itself depending on the number of pipes connected. For example a single pipe connected and the junction is an open ended pipe, two connected pipes and the junction transforms to a bend, three connected pipes the junction becomes a tee or wye and with four connected pipes the junction becomes a cross.

Make further connections so that we end up with a connected network as shown on the following image.



Turn on the pipe numbering from the flowsheet toolbar. Note that pipe numbers go from -1 ... -n and that other elements (nodes and text) are numbered 1 ... n.



Changing the default data using the flowsheet and data palette:

Up until this point no data entry has been made, we have focused on describing the element connectivity. This means that each element will have default data values according to the current environment set in use when the element was placed on the flowsheet (see Customizations and Environment section for more information about environment sets).

You can select any element on the flowsheet at any time by clicking on the element, after first using (clicking on) the selector icon. First we need to enter all the pipe lengths. Table 3 shows the pipe lengths that are fixed by the physical plant layout and also the number of bends in each pipe section.


Table 3

Pipe Number	Pipe Length (M)	Number of 90° Bends in Pipe
-1	5	2
-2	12	3
-3	3	2
-4	8	0
-5	3	2
-6	8	0
-7	3	2
-8	3	2
-9	18	5
-10	8	0
-11	3	2
-12	8	0
-13	3	2

To enter the pipe lengths we can use one of two approaches. Either we can select pipes from the flowsheet or we can select pipes from the Lists Tab in the *Data Palette*. We will use the flowsheet in this example.

We can reduce the amount of data entry we make by recognizing the fact that some of the pipes are identical. For example the main feed and return branches to each exchanger are identical (pipes -3, -5, -7, -8, -11 and -13). If we use the fact that we can make multiple selections on the flowsheet we can change the length of all 6 pipes with one edit.

There are many ways to make multiple element selections, but for now we will use the mouse-click method. To make multiple selections using mouse clicks on the flowsheet simply hold down the *Shift* key and click each element you wish to select. If you make a mistake and select the wrong element just click the element again and it will deselect. Don't forget to keep the *Shift* key depressed as you are making the multiple selections. Use this method to select the six identical branch pipes. If you release the *Shift* key and click anywhere on the flowsheet other than on a selected element you will lose your selections.



To enter the pipe length of 3 m for each selected pipe, click on the *Input* tab in the *Data Palette*, move to the *Length* row in the *Input* tab and change the length to 3.

Data Palette	
Messages	Input
Results	Chart
List	Watch
Unique Name	
Status	On
Length	3
Length Unit	m
Geometry	Cylindrical
Use Database Size	Yes
Nominal Size	2 inch
Classification	Schedule 40
Friction Model	Moody
Use Database Roughness	Yes
Roughness Description	Clean or new
Use Database Scaling	No
Scaling (0 to 50%)	0
Sizing Model	Economic Velocity
Heat Loss Model	Ignore Heat Loss/Gain
Draw Thickness [1..5]	1
Draw Color	clBlack
Properties on Flowsheet	Hide

Input Inspector Tab.

The length of all 6 pipes is changed in one edit. Change the length of the remaining pipes, (Hint: the header and return sections -4, -6, -10 and -12 are identical).

Time to save our work. Use the File Save menu to save your work now. It is good practice to regularly save your work.

To complete the pipe data entry we need to make 2 additional entries. For each pipe we need to specify a nominal size and we need to add further bends as shown in Table 3. We need to determine pipe size and FluidFlow can help us here, so we will defer this task and add the additional bends now.


There are 2 additional bends in each branch line, 3 in the supply line from the pump to the first branch (tee node 9) and 5 additional bends in the return line from the last return branch (tee node 12) to the cooling tower.

As we are dealing with an incompressible fluid, where the density change is small throughout the network we can avoid entering all bends individually. Instead use the Quantity row for each bend we add in the Input Inspector to reduce the number of bends we need to add.

Design Note: This approach is **NOT** recommended where density changes throughout a pipe section are significant, i.e. compressible fluids.

Select the *Junctions* Tab in the component palette and click on the bend, then drop this bend into pipe. If you need to create some additional length to pipe -1 on the flowsheet, click on the pump node (6), hold down the left mouse button and drag the node to a different location.

Add the remaining bends as shown highlighted in the flowsheet below.



Hold the *Shift* key and click on bends 14, 15, 16, 17, 18 & 19 and change the *Quantity* row in the *Input Inspector* of the *Data Palette* from 1 to 2.

Click on bend 13 and change the quantity to 3. Click on bend 20 and change the quantity to 5. This almost completes the data entry for the pipe data given in Table 3. All that remains for pipe entry is to set each pipe diameter.

You may have noticed that inserting an element in a pipe splits the pipe lengths into two equal segment lengths. This is the default behavior but can be changed based on personal preferences if desired. This can be achieved by selecting: Options | Environment | Component Defaults [F4].

Note, it is important to review all pipe lengths which have been affected as a results of inserting elements. In this case, we have set the length of the pipes in this system to reflect that shown in Table 4.

Table 4

Pipe Number	Pipe Length (M)	Pipe Number	Pipe Length (M)
-1	5	-12	8
-2	6	-13	1.5
-3	1.5	-14	6
-4	8	-15	1.5
-5	1.5	-16	1.5
-6	8	-17	1.5
-7	1.5	-18	1.5
-8	1.5	-19	1.5
-9	9	-20	1.5
-10	8	-21	9
-11	1.5		

Click on each heat exchanger on the flowsheet and change the default data to reflect the tube information provided in Table 1. The *Input Inspector* for HE2 is shown below.

Data Palette	
Messages	Input
Results	Chart
List	Watch
Unique Name	HE2
Status	On
Elevation	3
Elevation Unit	m
Pressure Loss Model	Standard Relationships
Fluid Side	Tubeside
Number of Tubes	165
Number of Tube Passes	2
Tube Diameter	12
Diameter Unit	mm
Tube Length	3
Length Unit	m
Heat Loss Model	Fixed Transfer Rate
Heat Transfer Direction	Into Network
Heat Transferred	170000
Heat Transfer Unit	Watt
Properties on Flowsheet	Hide

You have probably realised, that the number and content of the rows displayed in the Input Inspector is governed by the choices you make. For example changing the *Heat Loss Model* From *Ignore* to *Fixed Transfer Rate* means that you need to supply additional data and so the additional rows *Heat Transfer Direction*, *Heat Transferred* and *Heat Transfer Unit* appear. *Heat Transfer Direction Into the network* means that the exchangers are acting as coolers i.e. the process side is generating heat.

Two more entries in the Inspector and we are ready to make our first calculation. At the input boundary (node 4) we need to set the pressure, boundary temperature and ensure that the fluid is water. The *Input Inspector* should look like. (25°C inlet temperature and a pressure of 1 atm).

Data Palette	
Messages	Input
Results	Chart
List	Watch
Unique Name	Cooling Tower Sump
Status	On
Elevation	0.5
Elevation Unit	m
Pressure Model	Stagnation Pressure
Pressure	1
Pressure Unit	atm
Temperature	25
Temperature Unit	C
Fluid	water
Fluid Type	Newtonian/NN-NonSettling
Properties on Flowsheet	Hide

In the known pressure outlet boundary (5), we need to set the pressure to 1 atm + 30000 Pascals (1.3 ATM). This is the pressure required to overcome losses in the cooling tower flow distributor. We can leave the temperature and fluid at the default entries since the flow will be out at this boundary and therefore the temperature, flow and fluid will be determined by the calculation.

Data Palette	
Messages	Input
Results	Chart
List	Watch
Unique Name	Cooling Tower Feed
Status	On
Elevation	6
Elevation Unit	m
Pressure Model	Stagnation Pressure
Pressure	1.3
Pressure Unit	atm
Temperature	15
Temperature Unit	C
Fluid	water
Fluid Type	Newtonian/NN-NonSettling
Properties on Flowsheet	Hide

At the pump (node 6) we need to enter the design flow rate of 12.99 kg/s. The orientation of the pump should be set so that the red dot, which represents the pump discharge, points to pipe -2. If you need to change this click on the *Discharge Pipe (RED)* row in the *Input Editor*.

Messages	Input	Results	Chart	List	Watch
Unique Name					
Status		On			
Elevation		0			
Elevation Unit		m			
Automatically Size		On			
Sizing Model		Size for Flow			
Design Flow		12.99			
Flow Unit		kg/s			
Discharge Pipe (RED)		-2			
Solids Derating		None			
Heat Loss Model		Ignore Heat Loss/Gain			
Properties on Flowsheet		Hide			

Before we make the first calculation you should also check that elevations are correct for each element. In fluid flow calculations the relative elevations are important, which means that we need to select a datum or grade point. i.e. a point where all elevations are measured relative to. Normally we would select the ground to represent a 0 elevation. In this example we will take the pump centreline as representing 0 elevation. Check that your node elevations are:

Table 5


Node Number	Node Type	Elevation (M)
4	Inlet Boundary	0.5
6	Pump	0
13	Tee	0
9, 8, 7	Bend	0
14, 15, 16	Bend	1.5
1, 2, 3	Heat Exchanger	3
17, 18, 19	Bend	4.5
10, 11, 12	Tee	6
20	Bend	6
5	Outlet Boundary	6

To complete the data input make sure that all pipe lengths are set to the values in Table 4. At this stage we can leave the pipe diameters at the default values because our next task is to size all of the pipes.

Press the *Calculate* button. You should see FluidFlow quickly solve the network and flow directional arrows appear on the pipes in the flowsheet.

You can view the results in many ways. The simplest is to select the *Results* Tab in the *Data Palette* and click on each heat exchanger in turn on the flowsheet. In the results table the only row we are interested in at this stage is the mass flow through each exchanger. If we click on each exchanger in turn we can see that the flows do not match what we need from a cooling viewpoint. This means that the cooling system is unbalanced and will not work as specified in the initial design definition. You should be able to see that the flow through HE1 is greater than design and the flow through HE2 and HE3 is too low.

There is a useful way to view these results. Since we will be constantly referring to these flows we can show them on the flowsheet. To do this click on the 3 exchangers, while holding down the shift key to make a multi-selection then in the *Input Inspector*, change the Properties on Flowsheet row from Hide to Show, set the Alignment to Left and press the Properties button to obtain the following dialog.



Check the Flow in the Results tree and press the OK button. The flow rate through each heat exchanger will now be displayed on the flowsheet. If you need to change the flow units, you can either right mouse-click on the results tab, select Result Units [F9] and choose the desired flow units, in this case *kg/s*.

Pipe Sizing:

Before we balance the network we need to set the pipe sizes. There are three different options available in FluidFlow for sizing pipes: 1) Economic Velocity, 2) By Velocity & 3) By Pressure Gradient. This example will focus on using option 1: *Economic Velocity*.

Economic Velocity:

By selecting this option, we are allowing the software to determine the exact pipe size corresponding to the calculated economic velocity (shown in the Result). The economic velocity is a function of the fluid physical properties, the pipe materials, various capital and installation costs and the operating hours/year.

In FluidFlow each time the pressure loss through a pipe is calculated, its economic velocity and hence the economic pipe size are also calculated. By default these values are shown in the results table. Select the *Results* Tab in the *Data Palette* and click on the branch pipes in the flowsheet. As we move from each branch pipe we can see that the Exact Economic Size row in the results table ranges from 83, 63 & 54mm. This means that we should select the nearest standard pipe size to the suggested economic sizes calculated for each branch pipe. Since the default pipe size is 2", (unless this has been changed or you are using a different environment) we may not need to make any size changes to the branch pipes as this represents a size of 52.5 mm which is already reasonably close to the suggested *Exact Economic Size* for the branches. Perhaps a good starting point is to focus on the economic velocities and sizes for the main headers.

Check the supply or return header pipework and we can see that the exact economic size needed ranges from 124 mm to 58 mm. The calculated results for pipe node -2 are shown below. As we can see, the Size of the pipe is shown as 52.5 mm (default 2" size), the economic velocity is calculated as 1.23 m/s and the associated Exact Economic Size 115.9 mm.

The tee's at nodes 9 and 12 have connecting pipe sizes 4, 3 and 2" and pressure conversion effects from velocity to static or vice versa are taken into account when calculating pressure losses at the tee. Click on the tee, select the Input Tab and click the Nomenclature row in the Input Inspector if you need further information. For tees having 3 different branch sizes the loss relationships need to be extrapolated and you may find that you have warning messages to this effect.

Warning messages are there to help you decide if you need to make design changes. In this case the warning messages refer to the possible loss of calculation accuracy in the tee junctions because relationship data has been extrapolated. Since there are no other available pressure loss relationships available for these types of reducing tees we have no choice but to accept this warning. Still it is worthwhile checking on the calculated K values to ensure these are within an expected range (-2 to 10). You can also cross-check by using another loss relationship (say Miller type) and verify that the calculated K values and pressure losses are similar. This is the case here and so we can safely ignore the warnings. In fact we can turn off some of the less severe warnings, but this is not recommended.

Often, as engineers we like to keep header and return line sizes equal along the header and so a 4" or even 3" header/return line size is also a valid solution. Remember to take into account all possible operating scenarios and future considerations before making your final design decisions. For example, if we knew there was a possibility of a 4th heat exchanger being added at some time in the future then it would be a better solution to make the header and supply lines all 4". Pipe line sizing is always a balance between capital costs, operating costs and operating flexibility.

Pump suction lines should always be given careful consideration. We must always ensure that we have an entry head at the pump suction above the net positive suction head required by the pump + a safety margin. FluidFlow will detect and warn if adverse conditions exist and as a first guess we will use 4" pipe.

Based on the changes made so far, the calculated results for the pump are as shown below.

User Number	6	
Duty Flow	12.99	kg/s
Duty Pressure Rise	117938.1	Pa
Duty NPSH Available	10.4	m Fluid
In Stagnation Pressure	105054.6	Pa a
In Static Pressure	103802.1	Pa a
In Velocity	1.59	m/s
In Stag. Temperature	25.0	C

Balancing the network:


We need to add additional elements in order to balance the network. In this design case, we are going to automatically size orifice plates to achieve the required design flow rate of water in each branch. Using orifice plates will allow you to drop pressure in a controlled manner in each branch so that the correct flow distribution is achieved. However, it is important to note that balancing is wasteful of energy and perhaps, an alternative design solution may be more applicable to your specific design case. In any event, using orifice plates will help us achieve our flow distribution goal.

To obtain the distribution required we will use 3 orifice plates, one in each branch. Using orifice plates is a cheap solution to the distribution issue. However it may not prove very flexible if process conditions are likely to change. In this case using throttling valves may be a better solution.

Add the orifice plates as shown in the flowsheet below, set the Elevation of each orifice to be 3.75 m, set the Automatically Size function to ON and set the *Sizing Model* to *Size for Flow*. We must now enter the design flow rate for each orifice plate as calculated in Table 2. By defining the flow rate at each orifice plate, we are by default entering the total mass flow rate for the system. In the first pass calculation, we had already defined the total mass flow rate at the pump (12.99 kg/s). This will therefore lead to duplication in flow rates and as such, we need to change the pump *Sizing Model* to *Size for Pressure Rise*.

The design pressure rise from the pump can be established from adding the system pressure loss (calculated from pass 1 to be 117938.1 Pa) to the static head requirement which can be established from the equation $P = \rho \times g \times H$ ($P = 997 \times 9.80665 \times 6 = 58663$ Pa). The design pressure rise therefore becomes 176601.1 Pa. We can now enter this design value for the pump on the Input Inspector of the Data Palette.

Recalculate the model to refresh the results. We can now see a different flow distribution.



We can also see that FluidFlow has automatically determined the size of orifice plate required in order to achieve the design flow rate through each branch. If we view the results for the pump, we can see a design requirement of 12.99 kg/s @ 18.1 m fluid with a NPSHa of 10.4 fluid.

We have now almost completed the design. We will look at how to make final equipment specifications and how to consider the effect of likely operating scenarios in Part 2.

Summarizing you should have learned the following skills:

- How to select components from the component palette and how to place and move them on the flowsheet.
- How to connect pipes between nodes.
- How the Input Inspector works.
- How to make data changes to the flowsheet elements, both individually and as a selected group.
- How to show result text on the flowsheet
- How to interpret the calculated results to select or optimise a pipe size.
- How to balance a fluid network using orifice plates.

1.11 Design of a Cooling Water System - Part 2

This is the concluding part to the design of a cooling water system, started in Part 1.

In this part we will select a specific manufacturer's pump to perform at the operating duty calculated from the centrifugal pump element and consider the effect on the system if the heat load on exchanger 2 (HE2) is increased by 33%.

Click on the centrifugal pump element on the flowsheet and the results tab on the data palette. If you are using the default "System International" environment you should see a result similar to:

Duty Flow	12.99	kg/s
Duty Pressure Rise	176601.1	Pa
OR		
Duty Flow	12.99	kg/s
Duty Pressure Rise	18.1	m Fluid


i.e. the design flow of 12.99 kg/s of water at 25° C needs a pressure rise of 176601 Pa in order to operate at the design flows. We may wish to stop here and ask our preferred pump manufacturer to suggest a pump to supply this duty. To do this we will need to convert the pump duty flow to a suitable volumetric units and the calculated pressure rise needed to head units. You can use FluidFlow to do this for you automatically, however you may find it instructional to do the conversion now to m³/h and m Fluid. The density of water, obtained from the results table is 997 kg/m³ and so the calculated volumetric flow will be $12.99 \times 3600/997 = 46.9$ m³/h. The head that the pump is required to produce will be $176601/(997 \times 9.80665) = 18.1$ m Fluid.

This information, together with the operating fluid and temperature conditions is enough for the pump manufacturer to make a selection and under normal circumstances this is all that is required.

It is better to allow the manufacturer to make the selection for the following reasons: pump selection is often more than a simple hydraulic selection. Pump configuration, sealing and shaft load considerations, materials of construction etc are best handled by the manufacturer.

Even though the manufacturer is in a better position to make the selection it is still worthwhile and you can often get a more flexible design by making some additional hydraulic considerations.

For the purpose of illustration we will use the inbuilt pump selector to make the selection at this duty point. From the menu select 'Tools | Equipment Performance Viewers | Pump Performance' to create the dialog shown below.



To use this tool change the Design Flow to be 46.9 m³/h, and as you click on each pump in the list the performance data (Head, Efficiency, Best Efficiency and NPSH required) are shown for the currently highlighted pump.


This means that you can move through each pump in the database and view how it will perform in this system. The pump shown above would be a suitable selection from NPSH and efficiency viewpoint, but is unsuitable because the head developed is greater than that required by our duty (18.1 m fluid).

Viewing the pump database provides a number of pumps that will fulfill the hydraulic and system needs. You may wish to consider some of the following models:


Girdelstone 32ns.
DNP85-165.
FA 253-4402Z.
NM3196 2x3-10.

The best choice is the to select a pump operating near the best efficiency or a pump with the highest efficiency at the duty point.


To complete the example we will select the **Gould pump NM 3196 2x3-10 MTX**. The operating performance of this pump based on a design flow rate of 46.9 m³/h is as shown below.



To assign this pump to the model, click on the centrifugal pump node (6) and set "Automatically Size" to "Off". Change the pump model from the default pump, by clicking on the button in the Pump Model row in the Input Editor and select the **Gould NM 3196 2x3-10 MTX**.



Notice that the pressure developed by this pump is higher than that needed and that the orifice size on each branch has changed slightly in order to maintain the design flow rates specified.



As engineers we like to over design. Right !!! Before we congratulate ourselves on the design, we may wish to check that the selected pump is operating near to the Best efficiency point (BEP) and that the duty point is not near the pump run-out condition. If we are operating in the latter region, it would be wasteful of energy, have a larger NPSH requirement, increase pump wear and we would most likely need to oversize the motor.

This particular pump is operating in a reasonably good position. However, there may be an opportunity to reduce the pump power requirement and thus, improve the system operating efficiency. It is important however to give due consideration to the system design pressure requirements, in particular, the design pressure losses advised by the cooling tower manufacturer.

Lets consider the current set of results for the pump.

User Number	6	
Duty Flow	12.99	kg/s
Duty Pressure Rise	188296.5	Pa
Duty Efficiency (%)	60.87	
Duty Power	4.0	kW
Duty NPSH Required	1.4	m Fluid
Duty NPSH Available	10.4	m Fluid

If we wished to study energy saving measures, we could select a smaller pump, or better still we can reduce the impeller diameter to from 254 mm to around 224 mm. This will allow us some additional capacity if needed in the future.

Lets apply this change to the impeller diameter from the Input tab. of the *Data Palette*. When we recalculate the model, we can see that the affinity laws have been applied and the power requirement has reduced from 4.03 to 2.97 kW. We will also note however that the duty pressure rise has also reduced from 188296.5 to 133284.2 Pa. You may therefore wish to review this operating condition with the cooling tower manufacturer. Details of the results of this simulation are shown below.

1.12 Design of a Tank Farm Gas Collection System

In this example we are not concerned with building the model and data entry. Instead we focus on the engineering.

Problem Statement:

It is desired to collect together the air vents from a group of 5 storage tanks holding a flammable, obnoxious liquid. The vent gas is to be treated in an activated carbon bed before finally passing to atmosphere.

In this problem we are only concerned with the situation that occurs as the tanks are filling. In our scenario each tank, vents gas (for simplicity considered to be air), at the rate of which it can be filled. The exit gas vent from each tank is modeled as a known flow element, with the maximum tank fill rates already entered.

The remainder of the collection network has been built and can be opened from the \Examples folder "Non Sized Gas Collection System". Open the example and consider how we may answer the following question.

1. Size all pipes so that the operating pressure under maximum filling rates does not exceed that allowed under code API 650. This means no more than 1 psig operating pressure in each storage tank.


Considerations and approach:

We will take the worst case of all 5 tanks filling at one time.

To easily view the calculation result values we can use one of three possible techniques:

- We can configure and turn on the fly by results. In this way we can move the mouse over the flowsheet and look at the result values we are interested in.
- We can click the Results tab in the data palette on the left click on the flowsheet to select each component we are interested in.
- We can show the results on the flowsheet.

It is important to state at the outset that there are many solutions to this problem. For example we could increase all line sizes until the pressure in each tank dropped below 1 psig. This would undoubtedly work, but as the lines are made of stainless steel and are of a reasonable length we may not wish to over design in this way due to cost considerations.



To start, let us consider the tank pressures if we use 2" pipe throughout (this is the case if we open the example). You can see that each tank is over the maximum allowed pressure of 1 psig.

Click on any pipe and look at the results table in the data palette. You can see immediately that each pipe is already larger than the size recommended according to the economic size. This is an important point and illustrates that you cannot blindly set all pipe sizes to the suggested economic size in all cases.

Click on a few more components and consider the row titled "Non Recoverable Loss", this loss represents the pressure loss that can never be recovered. It is this value that we must impact (reduce) if we are to design a safe system.

You should quickly note that the majority of the system pressure loss occurs at over the packed bed. The packed bed represents a pressure loss of 0.6 psi out of a total of < 1psi available.

Using this knowledge, perhaps the best approach to take is increase the diameter of the bed to reduce the pressure loss, rather than increase the pipe size of each pipe. This now becomes a cost issue. For example is it less expensive to change the diameter of the bed, or use a different particle size in the bed rather than change the pipe sizes.

We do not have sufficient information to fully consider the available choices. What is important is that you recognise how to utilise the power of FluidFlow to consider the alternative design scenarios.

If you have the scripting module you can automate this process.

An acceptable design changing only pipe sizes downstream of the Tee junction (node 15) is saved as "Pipe Sized Gas Collection System".

1.13 Configuration and Environment

Nearly all aspects of the FluidFlow application can be configured and customized. The configuration settings that you change are saved, so that each time the application starts your own preferences are applied. Some of the configurations will be familiar, such as changing the position of tool bars, adding buttons, etc., because these customizations are commonly found in professional software.

Some aspects of the environment are stored as a subset called an Environment Set. You can make as many environment sets as you need and change between them interactively.


An environment set is closely associated with the default input data and units for every component (fluid equipment item) that is available from the component palette as well as how and what calculation results you wish to see.

Each environment set stores the following information, and can be easily accessed via a function key:


- F4 - Provides access to the default settings for each component available from within the program.
- F5 - Provides access to the data columns you wish to export to Excel.
- F6 - Allows you to set up Fly By Options. A 'fly by' is the window that appears as you move the mouse over a component on the active flowsheet. It is possible to set the fly by content for each component.
- F7 - Provides access to the columns you wish to print in your report, or export to Word, HTML, or PDF.
- F8 - Allows you to configure the contents of the table shown on the Results tab of the data palette.
- F9 - Allows you to individually set the calculated result units and the number of decimal places you wish to use.

After a new installation of FluidFlow there are 2 environment sets already made for you. "System International" and "US Basic". These should form the basis of changes you make. Rather than making the changes to any of the basic sets provided, it is a better idea to make a renamed copy and make the changes to the copy.

As an example of how to do this. First change environment to that you wish to copy from, you can do this from the combo box on the main application toolbar.



Then select from the menu 'Options | Environment | Save Environment' to a new name.



Use the combo box in the main toolbar to change to the newly created environment and then customize by say pressing F9 to change the result units in this set.

Property	Preferred Units	Dec. Places
Area	mm ²	1
Density	kg/m ³	2
Flow	l/min	4
Flow Coefficient Cv,Kv	usgpm/psi	3
Heat Transfer Coefficient	W/m ² C	2
Length	m	2
NPSH	m Fluid	1
Pipe Size	mm	1
Power	Watt	1
Pressure/Head	bar a	4
Pressure/Head Drop	bar	4
Pressure Gradient	Pa/m	2
Specific Heat Capacity	J/kg C	1
Temperature	C	1
Velocity	m/s	2
Viscosity	cP	3

Buttons: OK, Cancel, Help

Here we have made the following changes from the original copy, we are displaying flow in l/min instead of kg/s and we are displaying both pressure and pressure drop in bar a and bar. The number of decimal places shown has also been increased to reflect this change.

Load up an example such as "[FluidFlow3 Folder]\QA Incompressible Flow\Boosters\4 Pumps in Parallel 3 Operating" which has text on the flowsheet. Move to the Results tab on the data palette and then change environment set. You will see that the flowsheet results and the table results update immediately to show the new conditions.

1.14 Databases


A powerful feature of FluidFlow are the many associated databases that support and enhance the application. These include a database of fluid properties, databases that describe the performance and limits of fluid equipment items, materials databases that hold pipe sizing and pipe insulation information, and a database of manufacturers, costs, and user-defined areas of application.

1.15 Fluids Database


The fluids database contains comprehensive thermo physical data for over 850 fluids. Thermo physical properties (density, viscosity, thermal conductivity, specific heat, physical constants and critical values, heat of vaporization, vapor pressure, and surface tension) are stored so that FluidFlow can complete pressure loss calculations including heat transfer and phase change. The database is much more than a table of physical properties. Many "state of the art" physical property prediction methods are available, often used together with modern Equations of State such as Benedict

Webb Rubin, Lee Kesler, and Peng Robinson. There are special relationships for water and steam (IAPWS), air, and you can also mix fluids (non-reacting) by using the database tools or dynamically in the flowsheet.

An example of a pre-mixed fluid made by combining fundamental fluid components in the fluid database is natural gas. A typical definition, showing molar composition is illustrated below:



Alternatively fluids can be mixed on the flowsheet. The following example shows the mixing of 4 alcohols.




The scope of explaining the addition of a new fluid to the fluid properties database is a little outside the quick start guide. For detailed information on how to do this see the help file or user manual.

In the database section we will explain a simpler addition in the next section.

1.16 Database of Manually Operated Valves


As an example of how the various databases are structured we will look closer at the dataset of manually operated valves. The dataset of manual valves is actually a subset of a larger database containing all fluid equipment components or items. The full database describes performance, limitations, and usage of all items on the component palette.

To view, edit, delete, or add to the manual valves subset, make the selection from the 'Database | Valves' menu, to display the 'Database Editor - Valves' dialog:



The Database Editor is also used for viewing, editing, deleting, and adding other fluid equipment items so the skills we learn here can also be applied to other items of fluid equipment.

On the left side of the editor dialog is a tree control that enables you to quickly access the individual item you need in the hierarchy. You can reorganize the tree if this is more convenient. Below we see the valves data tree re-organized according to manufacturer. In this dataset there are 8 manufacturers of butterfly valves shown in alphanumeric order.



Adding new Data:


With all FluidFlow datasets the method of data entry is identical. In general we follow these steps:

1. Select the appropriate dataset - use 'Database | Dataset Name' from the application menu.
2. Press the 'Add' button.
3. Enter a unique name and press 'OK'.
4. Enter the data that describes the component (fluid equipment item).

Add a new Valve:

To add a new gate type valve, select 'Database | Valves' from the application menu. This will display the 'Database Editor - Valves' dialog, identical to that shown earlier in this section. Organize the tree according to Component Kind and click on the branch titled "Gate Valve".

After clicking at this branch the 'Add' button should be enabled. Click the 'Add' button enter a name say "My Valve" and press the 'OK' button. The Editor should look like:



You can now edit the default data via the Data Inspector. For example you could assign a manufacturer or several materials. The data available for this valve is provided by the manufacturer:

Size = 100mm with pressure loss data expressed as a Cv value in usgpm/psi. The pressure loss data is tabulated in Table 4.

Table 4

% Open	Cv (usgpm/psi)
100	600
80	500
60	400
40	280
20	150
10	70

After you enter at least 3 sets of data points a curve fit of the data points occurs automatically. You can change the type of curve fit and if you select a polynomial you can also fix the order. The graph allows you to visually judge how the curve fit appears over the whole of the possible range. You can also zoom the graph for more detail and make a printout from this dialog.

We cannot emphasize enough, that it is vital that you check your data after adding any new component. You need to check the data for continuity over all possible operating positions/range and that you have also entered all additional data needed.

1.17 Add a New Pump

As an additional exercise add a new (fictitious) centrifugal pump from the following data:

Max Operating Pressure = 10 m Water g
 Suction Size = 150 mm
 Discharge Size = 100 mm
 Data Operating Speed = 100
 Min Speed = 50
 Max Speed = 150
 Data Impeller diameter = 250 mm
 Min Impeller Diameter = 200 mm
 Max Impeller Diameter = 300 mm

It is possible to leave the suction and discharge values at 0. If you do this FluidFlow will not make any size check. FluidFlow makes size checks to ensure you connect up a correct pipe size to the suction and discharge flanges of the pump.

The Data Operating Speed and the Min and Max Speed can also be at the same value. You can do this if you do not intend to install a variable speed motor.


The Data Impeller Diameter and the Min Impeller and Max Impeller Diameters can also be set to the same value. This may be true if the pump only takes a fixed size impeller.

Then enter the capacity, efficiency, and NPSHr curves from Table 5.

Table 5


Flow (l/s)	Head (m fluid)	Efficiency (%)	NPSH (m fluid)
0	5	0	-
2	5.5	30	-
4	5.75	45	2.5
6	5.75	60	2
8	5.5	68	2.5
10	5	70	3
12	4	65	3.5
14	2.5	50	4
16	0	0	4.8

Min Flow limit = 2 l/s
 Max Flow limit (run out) = 12 l/s
 Name = [your own choice]



An Important point is you should note is the entry at Head = 0. You are unlikely to get this information from any manufacturer, so you must make an estimate. The estimate you make can be guessed (this is OK because we will never operate the pump anywhere near to this condition). When you make the guess at head of zero, ensure that you do not "upset" the shape of the curve for the valid data points by selecting a value that lies on a smooth curve. If you do not make this guess you run the risk of using the pump in a system that is difficult to solve (converge).

Now that we have added the data save by pressing the 'OK' button and use the pump in the following simple flowsheet.



Check that the flow and head of the pump used in the system lies on the curve that you have previously entered.

Index

- A -

Activation 1
activation code 1
Add a new pump 51
Add a new Valve 48
Adding new Data 48
Administrator 13

- B -

balance the network 20
Balancing 20
boundary 20
building the model 20

- C -

calculate button 20
component palette 15
Configuration 45

- D -

data entry 20
data input 15
data palette 15, 43
Database 48
Databases 46
default administrator password 13
default data 20

- E -

economic pipe size 20
economic velocity 20
Environment 20, 45
environment sets 45

- F -

flow balancing 20
Flowsheet 20
fluids database 46

- G -

gas collection 43

- H -

heat exchanger 20
Help 6
How to enter data 20
How to interpret results 20
How to make changes 20

- I -

Inlet Boundary 20
Installation 1, 6

- K -

Keeping current 5
known flow boundary 20
known pressure outlet boundary 20

- L -

Logon 13

- M -

model building basics 20
modules 1
multiple element selections 20

- N -

Network 6
network module 13

- O -

orifice plates 20
Outlet Boundary 20

- P -

physical properties 46
physical property prediction methods 46

pipe length 20
pipe numbering 20
pipe size 43
Pipe sizes 20
Pipe Sizing 20
piping network 15
Product Id 1
pump 20, 37

- Q -

Quantity 20
quick key 45

- S -

schematic layout 15
Setting Up Client 6
settings 45
Setup 1
synchronised 15
System Requirements 1

- W -

Welcome 1

Back Cover